




ENZO 3 DRAWERS STORAGE BED

ASSEMBLY INSTRUCTION



A: L1020 x D235 x H195mm

Drawer side of this bed is interchangeable.		Assembled drawer internal dimensions.
Option1: Left Handside	Option2: Right Handside	<p>Isometric view of the assembled drawer with internal dimensions:</p> <ul style="list-style-type: none"> Internal width: 140mm Internal depth: 530mm Internal height: 335mm
		

All measurements are approximate

Important Information

Please take the time to carefully read through all of these instructions before you commence building this bed.

Keep these instructions for future reference.

Make sure to unpack, inspect and check all contents to ensure you have received every component.

WARNING - Small components or parts could choke a child if swallowed.

WARNING - Do not use any power tools as this may damage the frame and will invalid any claim.

WARNING - This bed is not suitable for Children under 4 years due to risk of injury from falls.

It is recommended that you always follow the manufacturer's instructions to assemble this product.

We strongly recommend that you keep children away from the work area.

We recommend laying a sheet or blanket on the floor where you intend to work to avoid scratching this product and protect your floor.

This product is heavy. Take extreme care when lifting and use two people to avoid personal injury or damage to the product.

Assemble the product close to its intended final position in your room, so you do not need to move it too much.

Recommend Mattress Size: 90cm x 190cm (UK Single)

It is necessary to frequently ventilate the room in order to keep the humidity low and prevent mould in and around the bed.

Keep any sharp objects away from the bed frame.

Please dispose of all packing safely.

HANDY HINT: If you keep the hardware in a bowl during assembly, you will be less likely to lose them.

HEALTH AND SAFETY

DO NOT: jump on this bed frame.

DO NOT: use this bed frame if any part is missing, damaged or worn.

DO NOT: use this bed frame unless all fixings are secured.



DO NOT: push this bed frame as this will damage the legs.

WARNING: If placing this bed on a non-carpeted floor, you must place some protection under all legs to stop the bed frame from moving. If you do not adhere to this, then there is no guarantee if the bed frames collapse.


CAUTION

DO NOT: stand inside the draw area.

DO NOT: overload the internal storage draw.



YOU WILL NEED A SCREW DRIVER. NOT PROVIDED



DO NOT USE POWER TOOLS


Hardware

A



Cam Stud
71PCS

B



Cam
71PCS

C




M8 x 30mm
74PCS

D




Round Sticker
19PCS

E



CSK SCREW
M4 X 38MM
12PCS

F



M4 Allen key
1PC

G




Unitar Jcbc Screw
M6 x 55mm
12PCS

H




CSK SCREW
M3.5 X 16MM
23PCS

I




FELT PAD
6PCS

J



JCBC W SCREW
M6 X 30MM
30PCS

Parts







ALL PARTS ARE NUMBERED ACCORDINGLY

CARTON 1 OF 3		
NO	PART NAME	QTY
13	LEFT HAND SIDE RAIL	1
14	CENTER SUPPORT	1
15	RIGHT HAND SIDE RAIL	1
20	RIGHT DRAWER SIDE PANEL	3
21	LEFT DRAWER SIDE PANEL	3
22	DRAWER BACK PANEL	3
23	DRAWER BOTTOM PANEL	3
24	DRAWER BOTTOM SUPPORT	3
CARTON 3 OF 3		
NO	PART NAME	QTY
16	DRAWER DIVIDER	2
17	DRAWER DIVIDER	1
18	DRAWER DIVIDER	1
19	DRAWER FRONT PANEL	3

CARTON 2 OF 3		
NO	PART NAME	QTY
1	HEADBOARD TOP PANEL	1
2	HEADBOARD LEFT PANEL	1
3	HEADBOARD RIGHT PANEL	1
4	LOWER SHELF PANEL	1
5	UPPER SHELF PANEL	1
6	HEADBOARD BOTTOM PANEL	1
7	LEFT FRONT PANEL	1
8	RIGHT FRONT PANEL	1
9	CENTER STRETCHER	1
10	TOP STRETCHER	1
11	HEADBOARD BACK PANEL	1
12	FOOTBOARD	1
25	LVL SLATS	15
HARDWARE + ASSEMBLY INSTRUCTION		




Step 1


		
A	B	C
14 PCS	12 PCS	10 PCS



DO NOT USE POWER TOOLS AS THIS MAY DAMAGE THE FRAME AND WILL INVALIDATE ANY CLAIM. DO NOT USE POWER TOOLS




Step 2


		
A	B	C
10 PCS	11 PCS	8 PCS



DO NOT USE POWER TOOLS AS THIS MAY DAMAGE THE FRAME AND WILL INVALIDATE ANY CLAIM.


Step 3

		
A	B	C
13 PCS	5 PCS	6 PCS







DO NOT USE POWER TOOLS AS THIS MAY DAMAGE THE FRAME AND WILL INVALIDATE ANY CLAIM.

Step 4



B


9 PCS



DO NOT USE POWER TOOLS


DO NOT USE POWER TOOLS AS THIS MAY DAMAGE THE FRAME AND WILL INVALIDATE ANY CLAIM.

Step 5










F

1 PC




WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE

CORRECT	WRONG	
		
		









Step 6







F


1 PC

WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE

CORRECT	WRONG	
		
		



Step 7



F

1 PC


WHEN FITTING CAMS

ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE


CORRECT






WRONG





FRONT VIEW



Step 8




		
A	F	I
2 PCS	1 PC	2 PCS

WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE





DO NOT USE POWER TOOLS AS THIS MAY DAMAGE THE FRAME AND WILL INVALIDATE ANY CLAIM. DO NOT USE POWER TOOLS

Step 9




		
A	H	I
2 PCS	23 PCS	4 PCS


WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE




DO NOT USE POWER TOOLS AS THIS MAY DAMAGE THE FRAME AND WILL INVALIDATE ANY CLAIM.

Step 10

		
A	B	C
18 PCS	4 PCS	12 PCS






DO NOT USE POWER TOOLS AS THIS MAY DAMAGE THE FRAME AND WILL INVALIDATE ANY CLAIM.





DO NOT USE POWER TOOLS


Step 11

	
B	C
8 PCS	6 PCS




Step 12

	
B	C
10 PCS	8 PCS









Step 13




F



1 PC

WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE



CORRECT	WRONG	
		
		



Step 14



	
G	F
6 PCS	1 PC

WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE





Option1: Left Handside

Step 14.1



	
G	F
6 PCS	1 PC

WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE





Option1: Left Handside




Step 14.2


	
G	F
6 PCS	1 PC

WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE

CORRECT




WRONG








Option2: Right Handside

Step 14.3


	
G	F
6 PCS	1 PC

WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE



Option2: Right Handside







Step 15





D



19 PCS

WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE




CORRECT	WRONG	
		
		






Step 16



	
J	F
30 PCS	1 PC

WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE




Step 17

		
A	B	C
12 PCS	12 PCS	24 PCS




DO NOT USE POWER TOOLS AS THIS MAY DAMAGE THE FRAME AND WILL INVALIDATE ANY CLAIM. DO NOT USE POWER TOOLS



Step 18


E

12 PCS




Step 19




DO NOT USE POWER TOOLS AS THIS MAY DAMAGE THE FRAME AND WILL INVALIDATE ANY CLAIM. DO NOT USE POWER TOOLS

Step 20




WHEN FITTING CAMS
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING BOLT
TURN CLOCKWISE UNTIL SECURE

CORRECT	WRONG	




Step 21




DO NOT USE POWER TOOLS AS THIS MAY DAMAGE THE FRAME AND WILL INVALIDATE ANY CLAIM. DO NOT USE POWER TOOLS

Step 22





Drawer Assembly Completed

Step 23



Step 24



ENZO THREE DRAWERS STORAGE BED

General Care

Wipe clean with a slightly damp soft cloth.

Avoid the use of all household cleaners and abrasives.

When moving your furniture, carefully lift into place. Never drag or push the pieces across the floor as this will cause damage to the joints and could result in failure to the product that will invalidate the warranty.

Recommendations

Periodical re-tightening of fixings.

Warning

This bed frame is heavy. Please use an assistant when lifting.

Notes

We've tried to make this bed frame as easy to assemble as possible. In the unlikely event that you have problems putting it together or damaged or missing pieces, please contact your retailer directly you purchased it from who will be able to resolve any issues.