



LACY MIDSLEEPER

Assembly Instructions




The ladder of this bed is interchangeable.




Option 1



Option 2



Please make sure the 3 drawer chest / 2 door unit / quad unit have already been assembled prior to building the frame.



SAFETY ADVICE

Please take the time to carefully read through the whole of these instructions before you commence.

Keep these instructions for future reference.

Unpack, inspect and check of all of the contents.

Please dispose of all packing safely.

Small components parts could choke a child is swallowed.

We strongly recommend that you keep children well away from the work area.

It would be sensible to lay a sheet or blanket on the floor where you intend to work to avoid

Scratching this product and protect your floor.


This product is heavy. Take extreme care when lifting to avoid personal injury or damage to the product.

This bed is heavy. Always lift this bed with two people.

Assemble the product as close to its intended final position in the room as possible.

Keep any sharp object away from the bed frame.

HANDY HINT: If you keep the hardware in a bowl during assembly you will be less likely to lose them.



LACY MIDSLEEPER SAFETY WARNINGS AND GENERAL NOTES: IMPORTANT - READ CAREFULLY - RETAIN FOR FUTURE REFERENCE

WARNING - High beds and the upper bed of bunk beds are not suitable for children under six years due to the risk of injury from falls.

WARNING - Bunk beds and high beds can present a serious risk of injury from strangulation if not used correctly. Never attach or hang items to any part of the bunk bed that are not designed to be used with the bed, for example, but not limited to ropes, strings, cards, hooks, belts and bags.

WARNING - Children can become trapped between the bed and the wall, a roof pitch, the ceiling, adjoining pieces of furniture (e.g. cupboards) and the like. To avoid risk of serious injury the distance between the top safety barrier and the adjoining structure shall not exceed 75mm or shall be more than 230mm.

WARNING - Do not use the bunk bed / high bed if any structural part is broken or missing.



- Always follow the manufacturer's instruction.
- Prohibit horseplay on or under the bed. Always prohibit jumping on the bed.
- Prohibit more than one person on high bed and upper bunk.
- Always use the ladder for entering and leaving the high bed upper bed.
- Only use a mattress that is 1905mm (75") long and 915mm (36") wide on upper bunk bed. The top of the mattress shall be at least 160mm (6-1/4") below the edge of the safety barriers.
- Ensure thickness of mattress below the mark that had been made at the entrance of upper bunk.
- Ensure that ventilation of the room is necessary in order to keep the humidity low and to prevent mould in and around the bed.
- All assembly fastenings should always be tightened properly and that care taken that no fittings are loose.

WARNING - Do not use any power tools at this may damage the frame and will invalid any claim.

This item conforms the European Safety Standard - BS EN 747-1:2012+A

16cm

The top of the mattress
must not come above this
line




PART LIST

MODEL: LACY MIDSLEEPER


Carton 1 of 5

No.	Part Name	Pcs
A	LEG FL	1
B	LEG BL	1
C	LEG BR	1
D	LEG FR	1
E	FOOT BOARD PANEL	1
EL	HEADBOARD PANEL	1
P	SLAT	1
	Carton 2 of 5	
F	SIDE RAIL BACK - TOP	1
G	SIDE RAIL FRONT - BOTTOM	1
H	SIDE RAIL FRONT - TOP	1
J	SIDE RAIL CLEAT	1
JL	SIDE RAIL CLEAT	1
K	LEG SUPPORT RAIL	1
L	SIDE PANEL LADDER RIGHT	1
M	SIDE PANEL LADDER LEFT	1
N	STEP PANEL LADDER	3
Q	METAL BRACE	2
R	SIDE RAIL BACK - BOTTOM	1
	FITTING LIST	


PARTS LIST




Hardware




8 X 36
M6 X 13MM BARREL NUT




13 X 2
M6 X 35MM JCBC
BOLT SCREW




18 X 18
M7 X 32MM JCBC-W SCREW




19 X 26
M6 X 60MM JCBC
BOLT SCREW



20 X 54
M8 X 25MM PVC DOWEL




25 x 2
M6 x 50mm JCBC
BOLT SCREW




26 X 8
M6 X 110MM JCBC
BOLT SCREW




27 X 2
M6 X 12MM JOINT NUT




28 x 4
M6 x 20mm JCBC
BOLT SCREW



35 X 2
M4 X 30MM CHIPBOARD
SCREW





40 x 2
M4 ALLEN KEY




64 X 2
M6 X 15MM ADJUSTABLE
SCREW





91 X 54
Ø20MM PVC STICKER




STEP 2 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.




STEP 3 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.

18		X10
91		X10




STEP 4 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.








STEP 5 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.

8		X8
26		X8
40		X1
91		X8




STEP 6 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.





8		X12
19		X12
40		X1
91		X12




STEP 7 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.









STEP 8 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.

8		X4
19		X4
40		X1
91		X4





STEP 9 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.





8		X6
19		X6
40		X1
64		X2
91		X6




LADDER POSITION OPTION








STEP 11 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.

13		X2
27		X2
40		X1
91		X6


OPTION 1








STEP 12 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.

8		X4
19		X4
40		X1
91		X4
28		X4


OPTION 1





STEP 13 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.

18		X8
40		X1
91		X2
25		X2
8		X2





OPTION 1




91		X2
35		X2

This isometric view shows the assembled bed frame. The slatted base is fully installed. The storage unit at the foot of the bed features two doors and two drawers, each with a handle. The side rails are also visible, showing the integrated handrails.






STEP 11 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.

13		X2
27		X2
40		X1
91		X6


OPTION 2








STEP 12 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.

8		X4
19		X4
40		X1
91		X4
28		X4


OPTION 2





STEP 13 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.

18		X8
40		X1
91		X2
25		X2
8		X2

OPTION 2



STEP 14 DO NOT use any power tools as this may damage the bed frame and will invalidate any claim.

91		X2
35		X2

OPTION 2
FINISH

