




IMPORTANT - READ CAREFULLY
RETAIN FOR FUTURE REFERENCE

OSLO QUADRUPLE SLEEPER

ASSEMBLY INSTRUCTIONS



THE LADDER CAN BE FITTED ON THE RIGHT OR LEFT HAND SIDE

IMPORTANT INFORMATION

WARNING – High Beds and the upper bed of bunk beds are not suitable for children under six years due to risk of injury from falls.

WARNING – Bunk beds and high beds can present a serious risk of injury from strangulation if not used correctly. Never attached or hang items to any part of the bunk bed that are not designed to be used with the bed, for example, but not limited to ropes, strings, cords, hooks, belts and bags.

WARNING – Children can become trapped between the bed and the wall, a roof pitch, the ceiling, adjoining pieces of furniture (e.g. cupboards) and the like.

WARNING – Do not use the bunk bed / high bed if any structural part is broken or missing.

It is recommended that you always follow the manufacturer's instructions to assemble this product.





Always follow the manufacturer's recommended mattress size, as per these instructions and the bunk bed / high bed maximum mattress height marking on the item.

Width 120cm x Length 190cm with a Maximum Depth of 16cm.

It is necessary to frequently ventilate the room in order to keep the humidity low and to prevent mould in and around the bed.

Please periodically check all the fixings of the item and re-tighten when necessary.

This item conforms to European Safety Standards - BS EN 747-1: 2012 + A1:2015



Safety Advice

Please take the time to carefully read through the whole of these instructions before you commence.

Keep these instructions for future reference.

Unpack, inspect and check of all of the contents.

Please dispose of all packing safely.

Small components parts could choke a child if swallowed.

We strongly recommend that you keep children well away from the work area.

It would be sensible to lay a sheet or blanket on the floor where you intend to work to avoid scratching this product and protect your floor.


This product is heavy. Take extreme care when lifting to avoid personal injury or damage to the product.

This bed is heavy. Always lift the bed with two people.


Assemble the product as close to its intended final position in the room as possible.


















Keep any sharp objects away from the bed frame.

HANDY HINT: If you keep the hardware in a bowl during assembly you will be less likely to lose them.





Parts




Part List				Hardware List (found in box 1)		
Part	Description	Box	Qty	Part	Description	Qty
03	Top and bottom Headend/footend	1	4	A	1/4 x 80mm Screw 	8
07	Back Guard Rail	3	2	B	1/4" Elliptical nut 	8
08	Front Guard Rail	3	2	C	7,0 x 50 mm Screw 	18
09	Back Side Rail Support	3	1	D	4,0 x 35 mm CC Screw 	65
14	Central Support	3	2	E	Allen key 	01
15	Slats	4	30	G	4,0 x 25 mm CC Screw 	08
17	Ladder Side	3	1	I	4,0 x 16 mm CC Screw 	20
18	Small Ladder Side	3	1	J	7,0 x 80 mm Screw 	14
19	Ladder Step	3	3	K	10 x 40 mm Wooden dowel 	68
26	Top and Bottom back Side Rail	3	2	L	15 x 90 mm Wooden dowel 	04
27	Top and Bottom Front Side Rail	3	2	M	Wooden spacer 	2
30	Lower profiles	3	2	N	7,0 x 120 mm Screw 	16
31	Top profiles	3	2	O	Glue 	2
32	Upper Foot	2	2	P	Metal Bracket 	4
33	Upper Foot	2	2	R	18 mm Plastic cap 	52
34	Bottom foot	2	2	S	Plastic hole cover 8mm 	4
35	Bottom foot	2	2	T	Plastic hole cover 10mm 	8
36	Vertical Support	3	1			

You will need screwdriver and small mallet (not provided).



1



K		10x40	x20
---	--	-------	-----




2




K		10x40	x16
---	---	-------	-----



3

Lower Headboard




Upper Headboard







E	 4mm	x1
N		7x120 16

4




Upper Headboard



L		15x90	x4
K		10x40	x32
O		Glue	x2


5

Lower Bunk Headend



Lower Bunk

6




7

Lower Bunk





Do Not Use Power Tools

i		4,0X16	x2
D		4,0x35	x2




Side View



Screwdriver
(not provided)



8

Top View




Do Not Use Power Tools

Top View



Lower Bunk


Attache the side slat first by pushing the side rails together so that the slats is flush against the side rail, before inserting the screws.




Screwdriver
(not provided)

M		Spacer	x2
D		4,0x35	x4


9



Side View




Side View




Screwdriver
(not provided)

M		Spacer	x2
D		4,0x35	x26

Back View




Top View



Do Not Use Power Tools

Side View




Lower Bunk

Next attach the remaining slats.
Place the slats onto the side rail supports and
distribute evenly by using the spacer provided.

10


Upper Bunk

E		4mm	x1
B			x4
A		1/4X80	x4
J		7X80	x8




11

Upper Bunk


i		4,0X16	x2
---	---	--------	----



Do Not Use Power Tools



Side View




Screwdriver
(not provided)

12

Upper Bunk




Do Not Use Power Tools





Top View

Top View




Screwdriver
(not provided)

Attache the side slat first by pushing the side rails together so that the slats is flush against the side rail, before inserting the screws.



M		Spacer	x2
D		4,0x35	x4

13

Upper Bunk



Next attach the remaining slats.
Place the slats onto the side rail supports and
distribute evenly by using the spacer provided.



M		Spacer	x2
D		4,0x35	x26

14


ASSEMBLY OF UPPER AND LOWER BUNK



Back View




Back View




2 x




Do Not Use Power Tools

G		4,0x25	x8
---	---	--------	----

Back View




2 x




15



LADDER LEFT




LADDER RIGHT






ASSEMBLING LADDER
LEFT SIDE





ASSEMBLING LADDER
RIGHT SIDE




E		4mm	x1
C		7x50	x12
R			x12

16


Ladder on Right Side



Left Side View




E		4mm	x1
C		7x50	x4




C		7x50	x2
E		4mm	x1
J		7X80	x2





Do Not Use Power Tools




Back View



Back View



S		x4
T		x8
R		x40
D		4,0x35 x03



**Your Oslo Quadruple Sleeper Is Now
Complete And Ready To Use.**

GENERAL CARE

Wipe clean with a slightly damp soft cloth.

Avoid the use of all household cleaners and abrasives.

When moving your furniture, carefully lift into place. Never drag or push the pieces across the floor as this will cause damage to the joints and could result in failure to the product that will invalidate the warranty.

RECOMMENDATIONS

Periodical re-tightening of fixings

WARNING

This bed frame is heavy. Please use an assistant when lifting.

NOTES

We've tried to make this bed frame as easy to assemble as possible. In the unlikely event that you have problems putting it together or damaged or missing pieces, please contact your retailer directly you purchased it from who will be able to resolve any issue.